

BATTEN TRUING INSTRUCTIONS - April 14, 2003
(1) Do not attempt to true your battens on the ground or any other surface that is not both smooth and flat.
(2) Align your batten inside the outline on the diagram, matching the front batten tip and the top of the batten at the high point of the camber with the pattern. No part of the batten should be more than 1/4 inch from the indicated position. Do not attempt to correct deviations less than 1/4 inch.
(3) To avoid decambering the longer battens or damaging the sail, lift the keel at the rear enough to allow them to slide in as easily as the shorter battens.
(4) Check your battens for symmetry before every flight. You also should check your battens to the pattern at 10-setup intervals, or after any hard landing or other ground handling mishap.
(5) If you have any questions, please consult your dealer or Wills Wing at (714) 998-6359 / tech@willswing.com. Please read the additional maintenance and tuning information in your owners manual.

16.0

U2 145 2003.09.02 revised 2008.08 sp
Wills Wing, Inc. www.willswing.com