Notes:
12mm battens typically do not need correction for the life of the glider. Reshaping without breaking the battens requires professional skill and experience. Check for symmetry periodically but do not make any correction for deviations of less that 2cm from the pattern measured at the highest camber.

For T3 154/136, use the corresponding batten number to check the batten camber and reflex by aligning the front and rear independently to account for the variation in length.

Wills Wing T3 144
Batten Template 20191120

